



Slab Seeker Depth Locator Spincast Reel Part List

Key #	Description	Part No.	Key #	Description	Part No.
1	Front Cover Assembly	VR324-01	10	Gear Train Kit	WR4322-01
2	Spinner Head Assembly	WR310-01		7 - Crank Rod Nut	
3	Body Assembly	WR301-01		10A - A/R Ratchet Assembly	
4	Center Shaft Bearing	WR109-01		10B - Actuator - A/R Pawl	
5	Thumb Stop	WR009-01		10C - Keyed Drag Washer	
6	Back Cover Kit	WR4323-01		10D - Teflon Drag Washer	
	5- Thumb Stop			10E - Drive Gear	
	6A - Back Cover Assembly			10F - Friction Washer (Red)	
7	Crank Rod Nut	WR003-01		10G - Crank Shaft	
8	Crank Handle Kit includes:	FY4318-01		10H - Crank Shaft Washer	
	7 - Crank Rod Nut			10J - Drag Click	
	8A - Crank Handle Assembly			10K - Crank Shaft Screw	
9	Drag Star Kit	WR4322-01		10L - Pinion Assembly	
	9A - Drag Star Assembly				
	9B - Drag Spring				
	9C - Drag "D" Washer				